


Login

User Name (Default: support)

Password (Default: support)

Login



Connection Status

Primary Setup

Link Type

Wireless Setup--2.4G

Wireless Enable

RF Power: Low Middle High

Wireless SSID (Up to 32 ASCII)



2

Activate Windows
Go to Settings to activate

- Device Info
- Advanced Setup
- Laver2 Interface
- ATM Interface**
- ETH Interface
- WAN Service
- LAN
- NAT
- Security
- Parental Control
- ALG
- Bandwidth Control
- Routing
- DNS
- DSL
- Interface Grouping
- IP Tunnel
- Certificate
- Multicast
- IPTV
- Wireless
- Diagnostics
- Management

3

DSL ATM Interface Configuration

Choose Add, or Remove to configure DSL ATM interfaces.

Interface	Vpi	Vci	DSL Latency	Category	Peak Cell Rate(cells/s)	Sustainable Cell Rate(cells/s)	Max Burst Size(bytes)	Min Cell Rate(cells/s)	Link Type	Conn Mode	IP QoS	MPAAL Prec/Alg/Wght	Remove
atm0	8	35	Path0	UBR					EoA	VlanMuxMode	Support	8/WRR/1	<input type="checkbox"/>
atm1	0	32	Path0	UBR					EoA	VlanMuxMode	Support	8/WRR/1	<input type="checkbox"/>

Add Remove

4

Activate Windows
Go to Settings to activate Windows.

- Device Info
- Advanced Setup
 - Layer2 Interface
 - ATM Interface**
 - ETH Interface
 - WAN Service
 - LAN
 - NAT
 - Security
 - Parental Control
 - ALG
 - Bandwidth Control
 - Routing
 - DNS
 - DSL
 - Interface Grouping
 - IP Tunnel
 - Certificate
 - Multicast
 - IPTV
- Wireless
- Diagnostics
- Management

ATM PVC Configuration

This screen allows you to configure a ATM PVC.

VP: [0-255] **5**
VC: [0-65535] **6**

Select DSL Latency
 Path0 (Fast)
 Path1 (Interleaved)

Select DSL Link Type (EoA is for PPPoE, IPoE, and Bridge.)
 EoA
 PPPoA
 IPoA

Encapsulation Mode: ▼

Service Category: ▼

Minimum Cell Rate: [cells/s] (-1 indicates no shaping)

Activate Windows
Go to Settings to activate Windows

Device Info**Advanced Setup****Layer2 Interface****ATM Interface**

ETH Interface

WAN Service

LAN

NAT

Security

Parental Control

ALG

Bandwidth Control

Routing

DNS

DSL

Interface Grouping

IP Tunnel

Certificate

Multicast

IPTV

Wireless

Diagnostics

Management

 IPoAEncapsulation Mode: Service Category: Minimum Cell Rate: [cells/s] (-1 indicates no shaping)

Select Scheduler for Queues of Equal Precedence as the Default Queue

 Weighted Round Robin Weighted Fair QueuingDefault Queue Weight: [1-63]Default Queue Precedence: [1-8] (lower value, higher priority)VC WRR Weight: [1-63]VC Precedence: [1-8] (lower value, higher priority)

Note: VC scheduling will be SP among unequal precedence VC's and WRR among equal precedence VC's.

For single queue VC, the default queue precedence and weight will be used for arbitration.

For multi-queue VC, its VC precedence and weight will be used for arbitration.

7

Activate Windows

Go to Settings to activate Windows.

- Device Info
- Advanced Setup
 - Layer2 Interface
 - ATM Interface
 - ETH Interface
 - WAN Service** 8
 - LAN
 - NAT
 - Security
 - Parental Control
 - ALG
 - Bandwidth Control
 - Routing
 - DNS
 - DSL
 - Interface Grouping
 - IP Tunnel
 - Certificate
 - Multicast
 - IPTV
 - Wireless
 - Diagnostics
 - Management

Wide Area Network (WAN) Service Setup

Choose Add, Remove or Edit to configure a WAN service over a selected interface.

Interface	Description	Type	Vlan802.1p	VlanMuxId	Igmp	NAT	Firewall	IPv6	Mld	Remove	Edit
ppp0.1	pppoe_0_8_35	PPPoE	N/A	N/A	Disabled	Enabled	Enabled	Disabled	Disabled	<input type="checkbox"/>	Edit

9

Activate Windows
Go to Settings to activate Windows.

- Device Info
- Advanced Setup
 - Layer2 Interface
 - ATM Interface
 - ETH Interface
 - WAN Service**
 - LAN
 - NAT
 - Security
 - Parental Control
 - ALG
 - Bandwidth Control
 - Routing
 - DNS
 - DSL
 - Interface Grouping
 - IP Tunnel
 - Certificate
 - Multicast
 - IPTV
- Wireless
- Diagnostics
- Management

WAN Service Interface Configuration

Select a layer 2 interface for this service

atm1/(0_0_32) ▼

Back Next 10

- Device Info
- Advanced Setup
 - Layer2 Interface
 - ATM Interface
 - ETH Interface
 - WAN Service**
 - LAN
 - NAT
 - Security
 - Parental Control
 - ALG
 - Bandwidth Control
 - Routing
 - DNS
 - DSL
 - Interface Grouping
 - IP Tunnel
 - Certificate
 - Multicast
 - IPTV
- Wireless
- Diagnostics
- Management

WAN Service Configuration

Select WAN service type:

- PPP over Ethernet (PPPoE)
- IP over Ethernet
- Bridging

Enter Service Description:

For tagged service, enter valid 802.1P Priority and 802.1Q VLAN ID.
For untagged service, set -1 to both 802.1P Priority and 802.1Q VLAN ID.

Enter 802.1P Priority [0-7]:

Enter 802.1Q VLAN ID [0-4094]:

Network Protocol Selection:

11

PPP Username and Password

PPP usually requires that you have a user name and password to establish your connection. In the boxes below, enter the user name and password that your ISP has provided.

PPP Username: 12 @waves.iptv.sy

PPP Password: 13 *****wg

PPPoE Service Name:

Authentication Method:

MAC Clone: (eg XX:XX:XX:XX:XX:XX)

MTU: (576-1492,default:1460)

- Enable Fullcone NAT
- Dial on demand (with idle timeout timer)
- PPP IP extension
- Enable Firewall 14
- Use Static IPv4 Address
- Enable PPP Debug Mode
- Bridge PPPoE Frames Between WAN and Local Ports

Device Info

Advanced Setup

Layer2 Interface

ATM Interface

ETH Interface

WAN Service

LAN

NAT

Security

Parental Control

ALG

Bandwidth Control

Routing

DNS

DSL

Interface Grouping

IP Tunnel

Certificate

Multicast

IPTV

Wireless

Diagnostics

Management

PPPoE Service Name:

Authentication Method:

MAC Clone: (eg XX:XX:XX:XX:XX:XX)

MTU: (576-

1492,default:1460)

- Enable Fullcone NAT
- Dial on demand (with idle timeout timer)
- PPP IP extension
- Enable Firewall
- Use Static IPv4 Address
- Enable PPP Debug Mode
- Bridge PPPoE Frames Between WAN and Local Ports

Multicast Proxy

- Enable IGMP Multicast Proxy
- No Multicast VLAN Filter

15

16

Back

Next

Activate
Go to Settings

- Device Info
- Advanced Setup
 - Layer2 Interface
 - ATM Interface**
 - ETH Interface
 - WAN Service**
 - LAN
 - NAT
 - Security
 - Parental Control
 - ALG
 - Bandwidth Control
 - Routing
 - DNS
 - DSL
 - Interface Grouping
 - IP Tunnel
 - Certificate
 - Multicast
 - IPTV
- Wireless
- Diagnostics
- Management

Routing -- Default Gateway

Default gateway interface list can have multiple WAN interfaces served as system default gateways but only one will be used according to the priority with the first being the last one the lowest priority if the WAN interface is connected. Priority order can be changed by removing all and adding them back in again.

Selected Default Gateway Interfaces

ppp0.1 ▲



Available Routed WAN Interfaces

ppp1.1 ▲

Device Info

Advanced Setup

Layer2 Interface

ATM Interface

ETH Interface

WAN Service

LAN

NAT

Security

Parental Control

ALG

Bandwidth Control

Routing

DNS

DSL

Interface Grouping

IP Tunnel

Certificate

Multicast

IPTV

Wireless

Diagnostics

Management

Two vertical dropdown menus with arrows pointing left and right between them.

Use the following Static DNS IP address:

Primary DNS server:

Secondary DNS server:

17

Back

Activate Windows
Go to Settings to activate Windows

- Device Info
- Advanced Setup
 - Layer2 Interface
 - ATM Interface
 - ETH Interface
 - WAN Service**
 - LAN
 - NAT
 - Security
 - Parental Control
 - ALG
 - Bandwidth Control
 - Routing
 - DNS
 - DSL
 - Interface Grouping
 - IP Tunnel
 - Certificate
 - Multicast
 - IPTV
- Wireless
- Diagnostics
- Management

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP.

Connection Type:	PPPoE
NAT:	Enabled
Full Cone NAT:	Disabled
Firewall:	Enabled
IGMP Multicast:	Enabled
Quality Of Service:	Disabled

18

Click "Apply/Save" to have this interface to be effective. Click "Back" to make any modifications.

Back **Apply/Save**

- Device Info
- Advanced Setup
 - Layer2 Interface
 - ATM Interface
 - ETH Interface
 - WAN Service**
 - LAN
 - NAT
 - Security
 - Parental Control
 - ALG
 - Bandwidth Control
 - Routing
 - DNS
 - DSL
 - Interface Grouping
 - IP Tunnel
 - Certificate
 - Multicast
 - IPTV
- Wireless
- Diagnostics
- Management

Wide Area Network (WAN) Service Setup

Choose Add, Remove or Edit to configure a WAN service over a selected interface.

Interface	Description	Type	Vlan802.1p	VlanMuxId	Igmp	NAT	Firewall	IPv6	Mld	Remove	Edit
ppp0.1	pppoe_0_8_35	PPPoE	N/A	N/A	Disabled	Enabled	Enabled	Disabled	Disabled	<input type="checkbox"/>	Edit
ppp1.1	pppoe_0_0_32	PPPoE	N/A	N/A	Enabled	Enabled	Enabled	Disabled	Disabled	<input type="checkbox"/>	Edit

19

Device Info

Advanced Setup

Layer2 Interface

ATM Interface

ETH Interface

WAN Service

LAN

NAT

Security

Parental Control

ALG

Bandwidth Control

Routing

DNS

DSL

Interface Grouping

IP Tunnel

Certificate

Multicast

IPTV

Wireless

Diagnostics

Management

WAN Service Interface Configuration

Select a layer 2 interface for this service

atm1/(0_0_32) ▾

Back

Next

21

Activate Windows
Go to Settings to activate Windows.

WAN Service Configuration

Select WAN service type:

PPP over Ethernet (PPPoE)

IP over Ethernet

Bridging

22

Enter Service Description:

For tagged service, enter valid 802.1P Priority and 802.1Q VLAN ID.
For untagged service, set -1 to both 802.1P Priority and 802.1Q VLAN ID.

Enter 802.1P Priority [0-7]:

Enter 802.1Q VLAN ID [0-4094]:

23

Back

Next

- Device Info
- Advanced Setup
 - Layer2 Interface
 - ATM Interface
 - ETH Interface
 - WAN Service**
 - LAN
 - NAT
 - Security
 - Parental Control
 - ALG
 - Bandwidth Control
 - Routing
 - DNS
 - DSL
 - Interface Grouping
 - IP Tunnel
 - Certificate
 - Multicast
 - IPTV
- Wireless
- Diagnostics
- Management

Device Info

Advanced Setup

Layer2 Interface

ATM Interface

ETH Interface

WAN Service

LAN

NAT

Security

Parental Control

ALG

Bandwidth Control

Routing

DNS

DSL

Interface Grouping

IP Tunnel

Certificate

Multicast

IPTV

Wireless

Diagnostics

Management

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP.

Connection Type:	Bridge
NAT:	Disabled
Full Cone NAT:	Disabled
Firewall:	Disabled
IGMP Multicast:	Not Applicable
Quality Of Service:	Disabled

24

Click "Apply/Save" to have this interface to be effective. Click "Back" to make any modifications.

Back

Apply/Save

- Device Info
- Advanced Setup
 - Layer2 Interface
 - ATM Interface
 - ETH Interface
 - WAN Service**
 - LAN
 - NAT
 - Security
 - Parental Control
 - ALG
 - Bandwidth Control
 - Routing
 - DNS
 - DSL
 - Interface Grouping
 - IP Tunnel
 - Certificate
 - Multicast
 - IPTV
- Wireless
- Diagnostics
- Management

Wide Area Network (WAN) Service Setup

Choose Add, Remove or Edit to configure a WAN service over a selected interface.

Interface	Description	Type	Vlan802.1p	VlanMuxId	Igmp	NAT	Firewall	IPv6	Mld	Remove	Edit
atm1.2	br_0_0_32	Bridge	N/A	N/A	Disabled	Disabled	Disabled	Disabled	Disabled	<input type="checkbox"/>	Edit
ppp0.1	pppoe_0_8_35	PPPoE	N/A	N/A	Disabled	Enabled	Enabled	Disabled	Disabled	<input type="checkbox"/>	Edit
ppp1.1	pppoe_0_0_32	PPPoE	N/A	N/A	Enabled	Enabled	Enabled	Disabled	Disabled	<input type="checkbox"/>	Edit

Add Remove

- Device Info
- Advanced Setup
 - Layer2 Interface
 - WAN Service
 - LAN
 - NAT
 - Security
 - Parental Control
 - ALG
 - Bandwidth Control
 - Routing
 - Default Gateway
 - Static Route**
 - RIP
 - DNS
 - DSL
 - Interface Grouping
 - IP Tunnel
 - Certificate
 - Multicast
 - IPTV
 - Wireless
 - Diagnostics

25

Routing -- Static Route (A maximum 32 entries can be configured)

NOTE: For system created route, the 'Remove' checkbox is disabled.

IP Version	DstIP/ PrefixLength	Gateway	Interface	metric	Remove
------------	---------------------	---------	-----------	--------	--------

26

Device Info

Advanced Setup

Layer2 Interface

WAN Service

LAN

NAT

Security

Parental Control

ALG

Bandwidth Control

Routing

Default Gateway

Static Route

RIP

DNS

DSL

Interface Grouping

IP Tunnel

Certificate

Multicast

IPTV

Wireless

Diagnostics

Routing -- Static Route Add

Enter the destination network address, subnet mask, gateway AND/OR available WAN interface then click "Apply/Save" to add the entry to the routing table

27

IP Version:

IPv4 ▼

Destination IP address/prefix length:

10.1.0.0/24

Interface:

pppoe_0_0_32/ppp1.1 ▼

(optional: metric number should be greater than or equal to zero)

Metric:

1 (Range:1-9999)

Apply/Save

protv

Activ
Go to

- Device Info
- Advanced Setup
 - Layer2 Interface
 - WAN Service
 - LAN
 - NAT
 - Security
 - Parental Control
 - ALG
 - Bandwidth Control
 - Routing
 - Default Gateway
 - Static Route**
 - RIP
 - DNS
 - DSL
 - Interface Grouping
 - IP Tunnel
 - Certificate
 - Multicast
 - IPTV
 - Wireless
 - Diagnostics

Routing -- Static Route Add

Enter the destination network address, subnet mask, gateway AND/OR available WAN interface then click "Apply/Save" to add the entry to the routing table.

IP Version:

Destination IP address/prefix length:

Interface:

(optional: metric number should be greater than or equal to zero)

Metric: (Range:1-9999)

Apply/Save

27

liketv

Activate
Go to Setting